



Calibration in the IDIA pipeline

Srikrishna Sekhar

Jordan Collier
Brad Frank
Russ Taylor





Pipeline goals


- Full Stokes calibration with the aim of producing continuum images/polarization cubes/spectral line cubes
 - (Full Stokes required for maximizing sensitivity in Stokes I)

Pipeline Philosophy

- Use multi-measurement sets (MMS) to parallelize across a cluster, take advantage of MPI aware tasks in CASA
- “Do the right thing” - Sensible defaults, get phases, fluxes, and polarizations right




processMeerKAT.py
Build
config.txt



Convert MS to
MMS





Pre calibration flagging –
get rid of the worst RFI


Logic

Cluster Instruction

Data

Flagging

- Combination of clipping, tfcrop and rflag
- Set conservative limits while flagging pre-calibration
 - In principle tfcrop takes out the bandpass shape prior to flagging
- In general rflag more effective, particularly shorter baselines



Parallel hand calibration –
no cross hands &
polarization

```
logger.info(" starting antenna-based delay (kcorr)\n → %s" % calfiles.kcorrfile)
gaincal(vis=visname, caltable = calfiles.kcorrfile, field
       = fields.kcorrfield, refant = referenceant,
       minblperant = minbaselines, solnorm = False, gaintype = 'K',
       solint = 'inf', combine = '', parang = False, append = False)


logger.info(" starting bandpass → %s" % calfiles.bpassfile)
bandpass(vis=visname, caltable = calfiles.bpassfile,
          field = fields.bpassfield, refant = referenceant,
          minblperant = minbaselines, solnorm = True, solint = 'inf',
          combine = 'scan', bandtype = 'B', fillgaps = 8,
          gaintable = calfiles.kcorrfile, gainfield = fields.kcorrfield,
          parang = False, append = False)

logger.info(" starting gain calibration\n → %s" % calfiles.gainfile)
gaincal(vis=visname, caltable = calfiles.gainfile,
        field = fields.gainfields, refant = referenceant,
        minblperant = minbaselines, solnorm = False, gaintype = 'G',
        solint = 'inf', combine = '', calmode='ap',
        gaintable=[calfiles.kcorrfile, calfiles.bpassfile],
        gainfield=[fields.kcorrfield, fields.bpassfield],
        parang = False, append = False)

# Only run fluxscale if bootstrapping
if len(fields.gainfields) > 1:
    fluxscale(vis=visname, caltable=calfiles.gainfile,
              reference=[fields.fluxfield], transfer='',
              fluxtable=calfiles.fluxfile, append=False)
```





processMeerKAT.py
Build
config.txt



Post calibration flagging –
tighter RFI thresholds

Logic →
Cluster Instruction →
Data →



Clearcal call within
run_setjy.py

Cross hand calibration –
Full Stokes

Logic

Cluster Instruction

Data

Polarization calibration

- Need to estimate :
 - Instrumental leakage
 - Calibrator source polarization
- Do both by observing a single source over several parallactic angles

Polarization calibration

- CASA “helper” task GainfromQU estimates Q, U of source from gain variation vs. Parallactic angle
- Use this information to solve for X-Y phase and instrumental leakage

```
gaincal(vis=visname, caltable=gain1file, field=fields.fluxfield,
        refant=referenceant, solint='10min', minblperant=minbaselines,
        solnorm=False, gaintype='G',
        gaintable=[calfiles.kcorrfile, calfies.bpassfile,
                   calfies.xdelfile],
        gainfield = [fields.kcorrfield, fields.bpassfield,
                     fields.xdelfield], append=False, parang=True)


gaincal(vis=visname, caltable=gain1file, field=fields.secondaryfield,
        smodel=[1,0,0,0], refant=referenceant, solint='10min',
        minblperant=minbaselines, solnorm=False, gaintype='G',
        gaintable=[calfies.kcorrfile, calfies.bpassfile,
                   calfies.xdelfile],
        gainfield = [fields.kcorrfield, fields.bpassfield,
                     fields.xdelfield],
        append=True, parang=True)

# implied polarization from instrumental response
logger.info("\n Solve for Q, U from initial gain solution")
GainQU = qufromgain(gain1file)
logger.info(GainQU[int(fields.dpolfield)])

logger.info("\n Starting x-y phase calibration\n → %s" % xy0ambpfy)
gaincal(vis=visname, caltable = xy0ambpfy, field = fields.dpolfield,
        refant = referenceant, solint = 'inf', combine = 'scan',
        gaintype = 'XYf+QU', minblperant = minbaselines,
        smodel = [1.,0.,1.,0.], preavg = 200.0,
        gaintable = [calfies.kcorrfile,calfies.bpassfile,
                     gain1file, calfies.xdelfile],
```

Polarization calibration


- Limitations: Leakage and QU estimation assume a constant value across an SPW.
 - Reasonable for VLA/ALMA, with several small (~ 64 MHz) SPWs
 - Problematic for MeerKAT with one ~ 800 MHz SPW
- On axis calibration still good, in reasonable agreement with VLA polarization measurements




MIGHTEE XMM LSS 12

RMS : ~ 4 uJy/beam

Self-cal improvements




Fluxes



VLA vs MeerKAT XMM LSS

Catalogs courtesy Ian Heywood





Pixel histogram of the MeerKAT XMM LSS image

Plot courtesy Russ Taylor

Polarization cubes


- Stokes V a good indicator of calibration quality



Fractional polarization

Calibrator	Field	NVSS (1.4 Ghz) %	MeerKAT band average (1.2 Ghz) %
J0240-2309	CDFS	0.80	1.72
3C237	COSMOS	< 0.13	0.1
J0201-1132	XMM LSS	3.41	2.31

Polarization cubes



Stokes images of a single channel of the
XMM LSS pointing at 1120 MHz

Next steps

- Get off-axis, wideband polarizations working
 - Full Stokes AW projection in collaboration with NRAO, talk this afternoon
- Get more reliable wideband polarization
 - CASA is not RM “aware” over a wideband, single SPW. Workarounds are being tested.

Summary

- The IDIA pipeline produces Stokes I images with $\sim 8\text{-}10 \text{ uJy/beam rms}$ with no self-cal, and (currently) 4 uJy/beam after self-cal
- Fluxes typically accurate to $\sim 5\%$
- On axis polarization is good, but will improve once the wideband is accounted for correctly